




Cher client,

Attention !

Avant de pouvoir utiliser votre tondeuse robotisée, il peut arriver que vous deviez d'abord l'enregistrer à nouveau à la (nouvelle) station de charge.

(Le voyant de votre station de charge doit être VERT avant de pouvoir vous connecter)

Un nouveau signal de boucle peut être trouvé dans le menu “ Paramètres “ sous “sécurité”


Nouveau signal boucle

Le signal de boucle est sélectionné au hasard, créant un lien unique entre la tondeuse robotisée et la station de charge. Dans de rares cas, il peut être nécessaire de générer un nouveau signal de boucle.

Par exemple, si deux installations adjacentes utilisent un signal très similaire.

- Placez la tondeuse dans la station de charge
- Sélectionnez Nouveau signal de boucle dans le menu et appuyez sur OK

1.8 Aperçu de la structure du menu 2



Dear Customer,

PAY ATTENTION!

Before you can use your robotic lawnmower, you may have to register it again at the (new) charging station.

(Your charging station status LED must be GREEN before you can register it)

New loop signal can be found in the “Settings” menu under “Security”

New Loop Signal

The loop signal is chosen randomly to create a unique link between the robotic lawnmower and the charging station. In rare cases it may be necessary to generate a new loop signal.

For example, if two adjacent installations use a signal that is very similar.

- Place the mower in the charging station
- Select New Loop Signal in the menu and press OK.